Page 1

October-18-11 8:12:34 AM

Item ID:

D3230-041

**Revision ID:** 

Basket Wedge Assembly Item Name:

Required Date: 10/28/11

**Start Date:** 

10/18/11

Start Oty: 1.00

Reg'd Oty: 1.00

\*1\*

Accept

\*N900040100\*

Setup Start

**Cust Item ID:** 

**Customer:** 

Reference:

**Approvals:** 

Process Plan

QC:

Date:

Date:

Tooling:

SPC (Y/N):

Date:

Date:

Run

Sequence ID/ Work Center ID Operation

**Description** 

Set Up/ **Run Hours**  Tool ID

Tool # Plan

Qty Code

Accept **Qty** 

Reject Reject Number

Insp. Stamp

Draw Nbr

**Revision Nbr** 

D3230

Rev C

\*110\*

Large Fab

Large Fab

Memo

0.00

0.00

Large Fab

110

1-Cut 3/4 x 3/4 square tubing as per Dwg D3230

2- Drill and c'sink holes

3- cut mesh as per dwg 4 -Deburr & Remove all Markings From Material

5-Weld bushings and fabricate basket wedge assembly as per D3230

A/R SS ROD Batch: 114649



120

QC9- Inspect visual per QS1004- Fusion Welds

0.00

\*120\*

Memo

0.00

Quality Control

, · ·

## Work Order ID 75148

October-18-11 8:12:34 AM

Required Date: 10/28/11

\*75148\*

Item ID:

D3230-041

10/18/11

Accept

\*N900040100\*

Setup Start

**Revision ID:** 

Item Name: **Start Date:** 

Basket Wedge Assembly

Start Oty: 1.00

Reg'd Qty: 1.00

\*1\*

**Cust Item ID:** 

**Customer:** 

Reference:

**Approvals:** 

Process Plan:

Date:

Tooling:

Date:

Run

QC:

Date:

SPC (Y/N):

Date:

Tool#

Stop

Sequence ID/ **Work Center ID**  **Operation** Description

QC5- Inspect part completeness to step on W/O

Set Up/ **Run Hours** 

Tool ID

Plan Code

Accept Qty

Reject **Qty** 

Reject Number

Insp. Stamp

\*130\*

130

OC

Memo

**Quality Control** 

140

\*140\* Powdercoat

Powder Coating

Memo

IST COAT:

START TIME: **OVEN TEMPERATURE** 

White Gloss(Ref:4.3.5.1) per QSI005 4.3-Alum

FINISH TIME:

2ND COAT: START TIME:

OVEN TEMPERATURE:

FINISH TIME:

0.00

X9ML11/10/20

\*\*\*\* if necessary\*\*\*\*\*

				·	A .
-					
¥					
	•				
			•	•	
	•				
			ŕ		

Page 3

October-18-11 8:12:34 AM

D3230-041 Item ID:

**Revision ID:** Item Name:

Basket Wedge Assembly

10/18/11 **Start Date:** Required Date: 10/28/11

Start Oty: 1.00

Req'd Qty: 1.00

\*1\*

**Cust Item ID:** 

**Customer:** 

Reference:

**Approvals:** 

Process Plan:

QC:

Date:

Date:

**Tooling:** 

Accept

SPC (Y/N):

Date:

\*N900040100\*

Date:

Run

Stop

Setup Start

Sequence ID/ **Work Center ID** 150

\*150\*

Quality Control

**Operation** Description

QC3-Inspect Part Finish

Memo

Set Up/ **Run Hours** 

0.00

0.00

Tool ID

Tool # Plan Code

Accept Qty

Reject **Qty** 

Reject Number

Insp. Stamp

BR 11-10-20.

180

QC

\*120\*

Packaging

Packaging

Identify as per dwg & Stock Location:

0.00

0.00

Packaging

190

\*190\* QC

Quality Control

QC21- Final Inspection - Work Order Release

0.00

Memo

0.00

4 B

## **Picklist Print**

October-18-11 8:12:33 AM

Work Order ID:

75148

Parent Item:

D3230-041

Parent Item Name:

Basket Wedge Assembly

**Start Date: 10/18/11** 

Required Date: 10/28/11

Start Qty: 1.00

Required Qty: 1.00

	Comments:	IPP Rev:D 09-02-	·25 rev.c as per dv	vg DD	verified by:EC									
	Component Item ID/ Item Name	Replacement Item ID	Mfg/ Purch	Bin Item	Primary Location	Last Location	Route Seq ID	Unit of Measure	Qty on Hand	Qty per Kit	Total Qty		Date Issued	Status
ر ا	D2232-3 Basket Hinge		Manufactured	No			110	Each	5.0000	2	2	6	C/1.	10.18
	* , ,				<u>Location</u>		Loc Qty	<u>Lo</u>	oc Code			,		
	D2327-3 Spacer Bushing		Manufactured	No	ST (729	29	5 5	Each	18.0000	2	2			
			•		Location		Loc Qty	<u>Lc</u>	oc Code			(p)	11.10	.18
/	D3759-1		· · · · · · · · · · · · · · · · · · ·	No	WA 719	63	18 1 17	Each	87.0000	- - 5	5	0		
/	Bushing		Manufactured				-					// w	_	0
					<b>Location</b>		Loc Qty	<u>L</u> c	oc Code			06 10.	10.1	ð
	,				WA 723		85 85 2				5			
/	M304EX0.75-16F Expanded Metal Flat SS		Purchased	No	664		110	sf	779.7855.	5.15	5.42105	26		å
					Location WA		Loc Oty 779.78548	<u>Lo</u>	oc Code		(po	11110	. 18	
					$\sqrt{18}$	1896 1153	102.9036 53.3264 82.2683			5.	1210		`	·
					118 118 118	597	33.0983 73.01888 115.17						Į.	
													<i>i</i> .	

119180

320

بخ میکند

٠.				
			,	
	<b>6.</b>			

October-18-11 8:12:33 AM

Work Order ID:

75148

Parent Item:

D3230-041

Parent Item Name:

Basket Wedge Assembly

M304TS0.750W.065

304 SQ Tube .75x.75x.065W

Purchased

No

**Start Date: 10/18/11** 

686.1922

Required Date: 10/28/11

Start Qty: 1.00

25.2966

Required Qty: 1.00

26.628


Loc Code

110


Location Loc Qty MAT018 664.5280585 117636 67.9987 118773 596.529359 WA 6.0667 118181 6.0667 WA007 15.5974906 116267 14.628472 116763 0.9690186 Cpl 11.10.18

26.628


	,				٠
·					
	·.				




			,		
•					
. •					
		•			
					**************************************
				•	
	•				
			•		
•					
		•			
		*			




ž.			
•		ę'	
•			
		9+2+ <b>4</b> *	
	,		



		u <sup>e</sup> re.
•		
·		
ė		
	en e	



		•			
٠					
			•		
	·				
	•				•



		•	
4			
»			
	•		
			·
	,		
		ŧ.	
	•		
	•		